CLICK2 FORM™
solidThinking®



Windows

Click2Form - Installation Guide

© 2017 solidThinking, Inc. All rights reserved. | solidthinking.com

solidThinking Click2Form 2018 Installation Guide

This document describes the installation procedure for Click2Form 2018.

solidThinking Click2Form 2018 Main Installer

To execute the installation, double-click **Click2Form_2018_Win64.exe.**

On the Click2Form window that appears, click **OK**.



On the Installer window that appears, click **Next**.



On the Licence Agreement that appears, select the box: **I accept the terms of the License Agreement**, then click **Next**.



On the **Choose Install Folder** that appears, keep the default path or enter a path for the installation folder, then click **Next**.



On the **Rename Shortcut Folder** window that appears, keep the default name or enter a name for the shortcuts folder.

Opptional: select to add a Click2Form shortcut to your Desktop.
Opptional: Select to associate relevent file types with Click2form.

Click **Next**.



In the **Pre-Installation Summary** window that appears, click **Install**.



Invoking solidThinking Click2Form 2018

After the installation completes, you can invoke solidThinking Click2Form from the Windows Start Menu or from the Desktop icon, if you chose to install the icon.

solidThinking Click2Form 2018 appears in your Windows Start Menu under the **Click2Form 2018** folder:



To start Click2form 2018 from your Desktop, click:

Licensing

The application recognizes either node-locked licenses or floating licenses served from a license server, consuming HyperWorks Units.

You must set the appropriate environment variable to point to either the license file or the license server. The name of the variable is: "**ALTAIR_LICENSE_PATH**".

Use it to point to a file for a node-locked license or to a network license server in the simple form of port@hostname.

To set the ALTAIR_LICENSE_PATH variable on Windows

1. Go to Start.
2. Click on Control Panels.
3. Go to System and select Advanced system settings.
4. Select the Advanced tab.
5. Click Environment variables.
6. Under User Variables, select or create ALTAIR_LICENSE_PATH.
7. For Value: enter the port@host of your license server or the complete path and filename to the license file.

As an alternative setup when using a local license file, without defining ALTAIR_LICENSE_PATH, you can rename the license file as altair_lic.dat and drop it in the <Click2Form installation folder>/security folder.